



▲ #52-580-020

This Fowler Economy Dial Gage Stand #52-580-020 is budget priced, but has the essential features for proper work inspection.

- Accepts all lug-back indicators.
- Positive lock screw.
- Column is $\frac{5}{8}$ " from back edge of working surface. Column diameter is 1".
- Fine adjustment of $\frac{3}{8}$ ".
- Capacity of $6\frac{1}{2}$ " from working surface.
- Bracket with $\frac{1}{4}$ " bolt for dial indicator is $2\frac{1}{4}$ " from center of column.
- Fine adjustment knob for zero setting.
- Rapid preliminary positioning adjustment is featured.
- Ground steel post mounted at right angles to the base.
- Ground working surface $5\frac{1}{2}$ " x $4\frac{1}{4}$ ".

Economy Dial Gage Stand #52-580-016 with microfine adjustment knob for zero setting.

- Accepts all dial indicators with $\frac{3}{8}$ " stems
- Column $\frac{5}{8}$ " from back edge of working surface. Column diameter 1". Fine adjustment of $\frac{3}{8}$ ".
- Positive lock screw
- Capacity of $6\frac{1}{2}$ " from working surface
- Bracket with $\frac{1}{4}$ " bolt for dial indicator is $2\frac{1}{4}$ " from center of column
- Microfine adjustment knob for zero setting
- Microscrew fingertip control
- Ground steel post mounted at right angles to the base
- Ground working surface $5\frac{1}{2}$ " x $4\frac{1}{4}$ "



Order No.	Description
52-580-016	Economy Dial Gage Stand for lug back indicators.
52-580-020	Economy Dial Gage Stand $\frac{3}{8}$ " indicators.
54-618-460*	$\frac{3}{8}$ " to 8mm Bushing