



Mx100/Mx200 Factory Reset



Perform a Factory Reset for the Mx100 or Mx200 Readout using the following procedure.

Procedure:

- ✓ Power on the MxReadout.
- ✓ Enter the MxReadout main settings menu and select the "Exit Application" item(second from the bottom).
- ✓ Enter the Supervisor Password at the prompt and press OK.
- ✓ At the MxLauncher screen(three large buttons), press the Settings button(Gear Icon).
- ✓ Scroll to the bottom of the Setttings Menu and press the item called "System".
- ✓ From the System menu press the item called "Advanced".
- ✓ From the Advanced menu press the item called "Reset options".
- ✓ From the Reset options menu press "Erase all data(factory reset)" button. Confirm by pressing the "Reset Tablet" button at the bottom of the screen. Confirm again by pressing the "Erase Everything" button.

The MxReadout device will proceed with the full factory reset procedure. Please do not interrupt the process and ensure that power remains supplied to the device throughout the process. The readouts will automatically reboot at the end of the reset procedure



Help and Resources

Please visit the support section at www.metlogix.com for access to MetLogix product documentation.

Watch tutorial videos for popular Mx functions at <http://www.youtube.com/metlogix>

Join the discussion on Facebook, search "MetLogix".

Contacts

175 Canal Street, Suite 503, Manchester, NH 03101 USA

Tel: 603.836.4452

Fax: 603.369.6499

Email: support@metlogix.com

Web: www.metlogix.com

© Copyright 2022 All rights reserved. MetLogix, Inc.



Automation and Metrology International, LLC

1-888-354-2525 | sales@auto-met.com

8808 Tyler Blvd, Mentor, OH 44060 | Request a quote: auto-met.com