



Mx200 WiFi Printing Setup



Print data results from the Mx200 to a WiFi enabled printer by following the steps below.

Procedure

- ✓ Enter the Supervisor Password in the Mx200 by going into *Setup-->Password* and entering **111004**.
- ✓ Enable the WiFi radio in the Mx200 by going into *Setup-->System-->WiFi Settings* and sliding the on off switch in the top right corner to the right-hand position.
- ✓ Once the WiFi radio is enabled, detected wireless networks should be listed below. Select the WiFi network that your printer is connected to, and enter the password, if required.
- ✓ Use the Back Arrow button in the bottom toolbar to return to the Mx200 Main DRO view.
- ✓ Go back into *Setup-->Printouts-->Print Setup*.
- ✓ In the Printer Setup screen press on the drop-down menu in the top left corner of the screen and select your printer device from the list.
- ✓ Wait for the Print Preview in the center of this screen to populate with a sample Mx200 Data Report and then press the small, circular print button on the right side of the screen.
- ✓ A printout should be produced, and you should be returned to the Main Mx200 DRO view.

Once the above steps are completed, the printer should now be configured for use with your Mx200 Readout. All future printouts can be executed by simply going to the Mx200 Data View and Pressing the Print Softkey Button.



Help and Resources

Please visit the support section at www.metlogix.com for access to MetLogix product documentation.

Watch tutorial videos for popular Mx functions at <http://www.youtube.com/metlogix>

Join the discussion on Facebook, search "MetLogix".

Contacts

175 Canal Street, Suite 503, Manchester, NH 03101 USA

Tel: 603.836.4452

Fax: 603.369.6499

Email: support@metlogix.com

Web: www.metlogix.com

© Copyright 2022 All rights reserved. MetLogix, Inc.



Automation and Metrology International, LLC

1-888-354-2525 | sales@auto-met.com

8808 Tyler Blvd, Mentor, OH 44060 | Request a quote: auto-met.com